MOTA®

# Battery Case for Galaxy S4

Specifications and User Manual

## Welcome:

Thank you for purchasing the MOTA Battery Case for Samsung Galaxy S4. You will now be able to keep going when your phone's internal battery is calling it quits.

## Features:

- Easy to carry, light, and ergonomic design helps protect your phone from accidental damages. The included ultra-clear screen protector will help to keep the screen free from scratches and dust.
- Built-in Li-Polymer Battery with 2600 mAh capacity nearly doubles the battery life of your Samsung Galaxy S4. This high performance battery is much safer than lithium-ion batteries.
- Protective IC Circuit efficiently prevents short-circuits, over-charges, and malfunctions.
- Cut outs for all the Galaxy S4 features, use your phone without removing it from the case.

For product support, visit
www.mota.com/support/




1. Telescopic Buckle
2. Opening for Camera and Flash
3. Micro USB Charging Port
4. Battery Level LED lights
5. Opening for Speaker
6. On/Off Switch

## Using MOTA Battery Case:

1. Pull upward the telescopic buckle (top of the MOTA Battery Case) to open.
2. Slide your Galaxy S4 into MOTA battery case and ensure phone is securely connected to the micro USB connection on the battery case.
3. Push down the top of the MOTA Battery Case to secure the phone.
4. Press the ON / OFF Switch located on the back of your MOTA cattery case to activate or stop charging. Check your Galaxy S4 screen for charging signal.
5. LED lights on your MOTA Battery case will show you how much charging capacity is remaining. Press the ON / OFF switch once to check battery levels.

1 LED Light: 25% remaining
2 LED Lights : 50% remaining
3 LED Lights : 75% remaining
4 LED Lights : 100% remaining

## Notes:

Charging icon on your Galaxy S4 will revert to its normal status once the battery is fully drained from MOTA Battery Case.

For maximum battery life, press ON/OFF switch on the MOTA Battery case to stop charging your Galaxy S4 once the

## Charging MOTA Battery Case:

1. Connect the provided USB cable to your MOTA Battery Case.
2. Connect the USB cable to any USB power source (such as your computer) to start charging.
3. Continue to charge until the LED indicators show 4 lights.

## Product Specifications:

Output Voltage: 5V / 1A (max)
Input Voltage: 5V / 1A (max)
Capacity: 2600 mAh
Battery Type: Lithium-Polymer Battery
Charge Time: Approximately 5 hours
Cycle Life: 500 times
Weight: 75 g
Dimensions: 144 x 73 x 16 mm

## Package Contents

- Battery Case
- Screen Protector
- Micro to USB Cable
- User Manual

## Warning:

Read all instructions and warnings prior to using this product. Manufacturer shall not be liable to you or to any third party for any damaged you or any third party may suffer as a result of use, intended or unintended, or misuse of this battery in conjunction with any device or accessory other than the appropriate mobile device for which the batter is designed. Do not store battery case in high temperature environments including intense sunlight heat. Do not place battery case in fire or other excessively hot environment. Be cautious of excessive drops, bumps, abrasions, or other impacts to this battery, if there are any damages to the battery such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use immediately and contact manufacturer or dispose of it in an appropriate manner at your local battery-recycling center. Do not dissemble this battery case or attempt to modify it in any manner. Do not expose this battery case to moisture or submerge in liquid. Keep battery dry at all times. Do not attempt to charge the battery case using any method or connection other than the device's USB connector. Do not attempt to replace any part of this battery. If the battery case is intended to be used by a minor, purchasing adult agrees to provide detailed instructions and warnings to any minor to prior to use. All battery cases have gone through a quality assurance inspection. If you find that your battery is excessively hot, is emitting odor, is deformed, abraded, cut, or is experiencing or demonstrating any abnormalities, stop all battery use immediately and contact manufacturer. For extended storage, charge your battery case for one hour. Never dispose of battery case in garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental laws and regulations. Always take used batteries to your battery-recycling center.

Galaxy® is a registered trademark of Samsung ® Inc.
MOTA® is not affiliated to Samsung® Inc.

MOTA® is a trademark of UNorth® LLC.
Copyright © 2014 by UNorth, LLC. All Rights Reserved.
www.mota.com